


SETTING INSTRUCTIONS

MODEL 01-PC DUAL SEAL AUTO RESET 2" C/W TEST PORT TRIM



INSTALL CONTROL WITH EITHER PIPEWRENCH OR FLAT WRENCH ONTO A LOCKING BALL VALVE TO UTILIZE THE TEST PORTS ON THE TRIM